



Artikel-Nummer Article Code Número d'article Höveler produkta Číslo výrobku		Artikel Article Article Грудукт Výrobek	Inhalt Volume (cl)	Durchmesser Diameter (mm)	Höhe Height (mm)	Gewicht Weight (g)	Artikel-Nummer Article Code Número d'article Höveler produkta Číslo výrobku		Artikel Article Article Грудукт Výrobek	Inhalt Volume (cl)	Durchmesser Diameter (mm)	Höhe Height (mm)	Gewicht Weight (g)	Artikel-Nummer Article Code Número d'article Höveler produkta Číslo výrobku		Artikel Article Article Грудукт Výrobek	Inhalt Volume (cl)	Durchmesser Diameter (mm)	Höhe Height (mm)	Gewicht Weight (g)	Artikel-Nummer Article Code Número d'article Höveler produkta Číslo výrobku		Artikel Article Article Грудукт Výrobek	Inhalt Volume (cl)	Durchmesser Diameter (mm)	Höhe Height (mm)	Gewicht Weight (g)
TIM 2116 TIM 2121 TIM 2125 TIM 2127 TIM 2129 TIM 2131		Teller flach Plate flat Assiette plate Мелкая тарелка Talíř mělký	156 210 250 275 290 310	19 20 22 24 24 25	195 360 560 740 840 1000		TIM 0211		Tasse stapelbar Cup stackable Tasse empilable Чашка штабелирующаяся Šálek stoh.	10	58	56	110	TIM 0819		Tasse Cup Tasse Чашка Šálek	19	74	67	165	TIM 3830		Kaffeeanne o/Deckel Coffeepot w/o cover Cafetière sans couv. Кофейник без крышки Konvice kávová	33	107	300	
SQU 2116 SQU 2121 SQU 2125 SQU 2127 SQU 2131		Teller flach "Square" Plate flat "Square" Assiette plate "Square" Мелкая тарелка "Square" Talíř mělký "Square"	156 210 250 275 310	18 21 21 24 25	195 350 550 730 1005		TIM 0218		Tasse stapelbar Cup stackable Tasse empilable Чашка штабелирующаяся Šálek stoh.	18	77	62	170	TIM 0628		Tasse hoch Mug Tasse haute Чашка высокая Šálek vysoký	29	79	93	235	TIM 3850		Kaffeeanne o/Deckel Coffeepot w/o cover Cafetière sans couv. Кофейник без крышки Konvice kávová	53	132	440	
TIM 2119 TIM 2126		Teller flach „system“ Plate flat „system“ Assiette plate „system“ Мелкая тарелка „system“ Talíř mělký „system“	192 256	21 28	320 755		TIM 1716		Untertasse Saucer Sous-tasse Блюдце Podšálek	156	19	190		TIM 1716 TIM 1720 SQU 1716		Untertasse Saucer Sous-tasse Блюдце Podšálek	156 156 156	19 21 19	190 227 195	TIM 3710		Kaffeeanne o/Deckel Coffeepot w/o cover Cafetière sans couv. Кофейник без крышки Konvice kávová	100	171	630		
TIM 2227		Teller flach viereckig Plate flat quadratic Assiette plate carrée Тарелка мелкая четырёхгранная Talíř mělký čtyřhr.	240	25	680		SQU 1716		Untertasse Saucer Sous-tasse Блюдце Podšálek	156	21	227		TIM 1124 TIM 1133		Suppentasse stapelbar Cream soup cup stackable Tasse à consommé empilable Чашка для супа штабелирующаяся Šálek na polévku stoh.	25 34	97 103	50 62	200 240	TIM 3960		Kaffeeanne o/Deckel Coffeepot w/o cover Cafetière sans couv. Кофейник без крышки Konvice kávová	33	120		
TIM 1917 TIM 1919 TIM 1922		Teller tief Plate deep Assiette creuse Глубокая тарелка Talíř hluboký	171 192 223	34 34 36	250 345 430		TIM 0220		Tasse stapelbar Cup stackable Tasse empilable Чашка штабелирующаяся Šálek stoh.	20	77	63	185	TIM 1413		Schüssel Bowl Bol Салатник Miska	71	132	80	440	TIM 4160		Teekanne o/Deckel Teapot w/o cover Théière sans couv. Чайник без крышки Konvice čajová	36	77	305	
TIM 1929		Spezialteller tief Special plate deep Assiette spéciale creuse Глубокая тарелка Talíř hlub.(misa m.k.)	288	38	890		TIM 1716 TIM 1720 SQU 1716		Untertasse Saucer Sous-tasse Блюдце Podšálek	156 156 156	19 21 19	190 227 195		TIM 1418 TIM 1421 TIM 1424		Schüssel Saladier Bol Салатник Mísa	170 260 370	183 215 243	87 99 105	740 1130 1380	TIM 3960		Teekanne o/Deckel Teapot w/o cover Théière sans couv. Чайник без крышки Konvice čajová	33	120		
SQU 1917 SQU 1919 SQU 1922		Teller tief "Square" Plate deep "Square" Assiette creuse "Square" Глубокая тарелка "Square" Talíř hluboký "Square"	172 193 224	34 34 36	270 340 425		TIM 1716 TIM 1720 SQU 1716		Tasse stapelbar Cup stackable Tasse empilable Чашка штабелирующаяся Šálek stoh.	27	84	72	200	TIM 3032		Platte rechteckig Platter rectangular Plat rectangulaire Блюдо четырёхгранное Podnos čtyřhranný	327 x 229	32	940	TIM 4302		Zuckerbol o/Deckel Sugar bowl w/o cover Sucrier sans couv. Сахарница Cukřenka	28	98	165		
TIM 0209		Tasse stapelbar Cup stackable Tasse empilable Чашка штабелирующаяся Šálek stoh.	9	59	53	95	TIM 1716 TIM 1720 SQU 1716		Untertasse Saucer Sous-tasse Блюдце Podšálek	156 156 156	19 21 19	190 227 195		TIM 4326		Suppenterrine o/Deckel Souptureen w/o cover Soupière sans couvercle Супница Mísa polévková	260 231	109	1700	TIM 4813		Eierbecher Egg cup Coquetier Подставка для яйца Kalíšek na vejce	124	19	585		
TIM 1711		Untertasse Saucer Sous-tasse Блюдце Podšálek	130	18	130		TIM 0810		Tasse Cup Tasse Чашка Šálek	9	59	53	95	TIM 3515 TIM 3530 TIM 3550 TIM 3410		Giesser ohne Henkel Creamer w/o Handle Crémier sans anse Молочник без ручки Mlékovka bez ouška	4	53	60	TIM 5011		Salzstreuer Salt shaker Salière Солонка Syrátko sůl	56	55			
SQU 1713		Untertasse "Square" Saucer "Square" Sous-tasse "Square" Блюдце "Square" Podšálek "Square"	130	18	125		TIM 1711 SQU 1713		Tasse Cup Tasse Чашка Šálek	9	59	53	95	TIM 3515 TIM 3530 TIM 3550 TIM 3410		Milchkanne Milk pot Pot à lait Молочник Mlékovka	15 34 60 100	84 107 135 171	170 290 420 730	TIM 4608		Vase Tablevase Vase Ваза Váza	78	215			



D1938 Pyramid

14677 Barocco
14768 Barocco

D2233 Trinidad

D1609 Charleston



Porzellanfabrik Langenthal AG

Bleienbachstrasse 22
CH-4900 Langenthal
Tel. +41 (0) 629 190 404
Fax: +41 (0) 629 190 400
info@suisse-langenthal.ch
www.suisse-langenthal.ch

Lilien Austria GmbH

Dr. Adolf Altmann-strasse
A-5020 Salzburg
Tel. +43 (0) 662 824 176
Fax: +43 (0) 662 830 177
office @lilien.at
www.lilien.at

G. Benedikt Karlovy Vary s.r.o.

1. Máje 30
CZ-360 06 Karlovy Vary
Tel. + 42 (0) 353 406 111
Fax: + 42 (0) 353 406 325
info@gbkv.cz
www.gbkv.cz

TIME / TIME SQUARE

